Soft Water

SYMPTOMS

Water spots are removed with soap and water.

Hard Water

SYMPTOMS

Water spots are removed with vinegar.



Silica Water

SYMPTOMS

Water spots are not removed with vinegar.





Clean, once every 15 showers, with a 50/50 solution of vinegar and water.



Clean, once every 10 showers with Soft Scrub Cleanser and a Scotch-Brite Non-Scratch sponge.

Cleaning frequency recommendations are guidelines only. Actual cleaning frequency will depend upon humidity, degree of water hardness, shower temperature and other variables. In cases with extremely high silica content, it may be helpful to squeegee as needed between cleanings.

